











OMANN JUN´S MØBELFABRIK



Montagevejledning ORIENT med Q-bæream Mounting instructions ORIENT with Q-support arm Instruction montage pour ORIENT système Q




Caution: Do not use with 110 – 230V

| Pos. | Q. | Type | Bit | |
|------|----|--------|-----|----|
| S1 | 8 | M8x20 | 5 | 28 |
| S2 | 4 | M6x12 | 5 | 22 |
| S3 | 8 | 4.5x20 | T20 | 74 |
| S4 | 4 | 4.5x55 | T20 | |
| S5 | 4 | 5x16 | T20 | 53 |
| S6 | 2 | 3.5x17 | T20 | 55 |
| S7 | 2 | | | |
| S8 | 6 | ∅18x4 | | |


O M A N N

Montagevejledning kabelbakke Mounting instructions cable tray Instruction de montage



1






2



Alternative with brackets - incl. in package






Function:



O M A N N

Montagevejledning CPU holder
Mounting instructions CPU holder
Instruction de montage CPU



| Pos | Q. | Type | Bit | | |
|-----|----|-------|-----|---|----|
| | 4 | M4x40 | PZ2 |  | 15 |
| | 2 | M6x12 | U5 |  | |